



Russell Hobbs

FUSION 5 KG

TAB SCALE

INSTRUCTION MANUAL

SAFETY INSTRUCTIONS

This product is not a toy.

This product contains no user serviceable parts.

Improper repairs may place the user at risk of harm.

Keep the product out of the reach of children.

Do not immerse the product in water or any other liquid.

Do not attempt to dismantle the product.

Do not place or store the product near direct sunlight or direct heat sources or in a damp environment.

This product is a high precision device; handle it with care.

Incorrect use of the product may cause damage.

The manufacturer is not responsible for any injury or damage occurring from incorrect usage or handling.

This product is intended for domestic use only. It should not be used for commercial purposes.

WARNING

THIS PRODUCT CONTAINS A BUTTON/COIN BATTERY

Swallowing can cause severe or fatal injuries within 2 hours.
Keep batteries out of reach of children (whether new or used).
If you think batteries may have been swallowed or placed inside any part of the body, seek immediate medical attention.



CAUTION: Vigilance must be maintained with 'flat' or spare button or coin batteries in the home and the products that contain them.

There are no obvious specific symptoms when a button or coin battery is stuck in a child's oesophagus (food pipe). However, the child might exhibit the following symptoms:

- Excessive coughing, gagging or drooling
- Appear to have a stomach upset or virus
- Vomiting
- Pointing to their throat or stomach
- Pain in their abdomen, chest or throat
- Tiredness and lethargy
- Be quieter or more clingy than usual

- Loss or reduction of appetite
- Refusal or inability to eat solid foods

A specific symptom of button or coin battery ingestion is vomiting fresh (bright red) blood. Seek immediate medical attention if this occurs.

BATTERY SAFETY

Do not short-circuit a cell or battery.
Check that the battery compartment is secure.
If the battery compartment does not close securely, stop using the product and keep it away from children.
Batteries are to be inserted with the correct polarity.
Remove any batteries from the product when it is not being used for a long period of time to avoid leakage.
In the event of the batteries leaking, do not allow any liquid to come into contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice.
Keep batteries out of the reach of children.
Remember to keep button

cell batteries away from children at all times as they can easily be swallowed. If you think batteries have been swallowed or placed inside any part of the body, **seek immediate medical attention.** Exhausted batteries must be removed and disposed of safely.

Do not crush, puncture, dismantle or otherwise damage batteries.
Do not expose batteries to heat or fire as they may explode.

Do not subject batteries to mechanical shock.
To dispose of any batteries, take them to a local recycling station. Contact the local government offices for details.
This product requires 1 x 3 V CR2032 button cell battery (included).

CARE AND MAINTENANCE

Clean the scale with a soft, damp, lint-free cloth.
Do not use harsh or abrasive detergents to clean the scale.
Always use the scale on a flat, hard surface.

INSTALLING AND REPLACING THE BATTERY

Activate the battery by turning the scale on its back and then pull out the tab, tucked underneath the battery.

STEP 1: To replace or install the battery, turn the scale onto its back, remove the screw and then the battery cover. Once opened, remove the exhausted battery.

STEP 2: Insert the new battery (1 x 3 V CR2032), observing the correct polarity, then replace the cover. Use caution when tightening the screw, to avoid damaging the cover.

NOTE: Take care when removing the exhausted battery and make sure to dispose of it properly.

USING THE 5 KG TAB SCALE UNIT CONVERSION

To switch between weight units, press **'MODE'** to cycle through the available options.

TO BEGIN WEIGHING

STEP 1: Place the scale onto a flat, stable surface.

STEP 2: Place a suitable bowl (if needed) onto the scale before turning it on.

STEP 3: Press the **'ZERO'** button to activate the scale. Wait for the LCD display to show the weighing screen.



STEP 4: Place the weighing objects onto the scale and the LCD display will show the weight.

ZERO FUNCTION

To weigh different items consecutively without removing them from the scale, place the first item onto the scale and take the weight reading. Press **'ZERO'** to reset the scale reading to **'0'** before adding the next item. Repeat as is necessary.



AUTOMATIC SHUT-OFF

Automatic shut-off occurs if the scale has been inactive for approx. 2 minutes to preserve power. To activate the scale again, press **'ZERO'**.

WARNING INDICATORS



LOW POWER: Replace the battery.



ERROR: Maximum weight exceeded (5000 g/11 lbs); reduce the weight on the scale.



Disposal of Waste Batteries and Electrical and Electronic Equipment

■ This symbol on the product, its batteries or its packaging means that this product and any batteries it contains must not be disposed of with household waste. Instead, it is the user's responsibility to hand this over to an applicable collection point for the recycling of batteries and electrical and electronic equipment. This separate collection and recycling will help to conserve natural resources and prevent potential negative consequences for human health and the environment due to the possible presence of hazardous substances in batteries and electrical and electronic equipment, which could be caused by inappropriate disposal. Some retailers provide take-back services which allow the user to return exhausted equipment for appropriate disposal. **It is the user's responsibility to delete any data on electrical and electronic equipment prior to disposal.** For more information about where to drop batteries, electrical and electronic waste off, please contact the local city/municipality office, household waste disposal service, or the retailer.

Supplied by

UP Global Sourcing UK Ltd., UK, Manchester OL9 0DD, Germany, 51149 Köln
under licence from Spectrum Brands (UK) Limited.

Russell Hobbs is the registered trademark of Spectrum Brands (UK) Limited.

www.russellhobbs.com

Made in China.

CD181218/MD260922/V5

